



Solder Side

- ② Cut trace to pin 40 U33
- ③ Jumper from U33 pin 40 to U29 pin 6
- ④ Add a drop of RTV so that the sharp IC leads of U33 don't pierce the jumper.

NO. : 680120		
REV: A		
DATE: 8-11-94		BOARD
MP-1 PLUS AND CLASSIC		LAYER 3 SOLDER SIDE
SHEET 3 OF 4		MASTER WORK -

